

**FURUNO**

# FI-504 MULTI FI-507 MULTI XL Instrument



**FURUNO ELECTRIC CO., LTD.**

[www.furuno.co.jp](http://www.furuno.co.jp)

All brand and product names are trademarks, registered trademarks or service marks of their respective holders.

**ECF**

(Elemental Chlorine Free)

The paper used in this manual  
is elemental chlorine free.

**FURUNO ELECTRIC CO., LTD.**

9-52 Ashihara-cho,  
Nishinomiya, 662-8580, JAPAN

Telephone : +81-(0)798-65-2111

Fax : +81-(0)798-65-4200

• FURUNO Authorized Distributor/Dealer

All rights reserved. Printed in Japan

Pub. No. OME-72690-B

(HIMA ) FI-504/507

A : OCT . 2007

B : FEB . 12, 2009



\* 0 0 0 1 6 7 3 3 4 1 1 \*

# IMPORTANT NOTICES

---

## General

- The operator of this equipment must read and follow the descriptions in this manual. Wrong operation or maintenance can cancel the warranty or cause injury.
- Do not copy any part of this manual without written permission from FURUNO.
- If this manual is lost or worn, contact your dealer about replacement.
- The contents of this manual and equipment specifications can change without notice.
- The example screens (or illustrations) shown in this manual can be different from the screens you see on your display. The screens you see depend on your system configuration and equipment settings.
- Save this manual for future reference.
- Any modification of the equipment (including software) by persons not authorized by FURUNO will cancel the warranty.
- All brand and product names are trademarks, registered trademarks or service marks of their respective holders.

## How to discard this product


Discard this product according to local regulations for the disposal of industrial waste. For disposal in the USA, see the homepage of the Electronics Industries Alliance (<http://www.eiae.org/>) for the correct method of disposal.

## How to discard a used battery

Some FURUNO products have a battery(ies). To see if your product has a battery(ies), see the chapter on Maintenance. Follow the instructions below if a battery(ies) is used.


### In the European Union

The crossed-out trash can symbol indicates that all types of batteries must not be discarded in standard trash, or at a trash site. Take the used batteries to a battery collection site according to your national legislation and the Batteries Directive 2006/66/EU.



### In the USA

The Mobius loop symbol (three chasing arrows) indicates that Ni-Cd and lead-acid rechargeable batteries must be recycled. Take the used batteries to a battery collection site according to local laws.





### In the other countries




There are no international standards for the battery recycle symbol. The number of symbols can increase when the other countries make their own recycling symbols in the future.









# SAFETY INSTRUCTIONS

The operator of this equipment must read these safety instructions before attempting to operate the equipment.

|  |   |
|--|---|
|  <b>WARNING</b> | Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury. |
|  <b>CAUTION</b> | Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.  |

|  |  |  |
|--|--|--|
|  Warning, Caution |  Prohibitive Action |  Mandatory Action |
|--|--|--|






## Safety instructions for the operator


|  |   |
|--|---|
|  <b>WARNING</b> |   |
|                 | <b>Do not open the equipment.</b><br>Only qualified personnel should work inside the equipment.   |
|               | <b>Do not disassemble or modify the equipment.</b><br>Fire or electrical shock can result if the equipment is modified.   |
|               | <b>Do not operate the equipment with wet hands.</b><br>Electrical shock can result.   |
|               | <b>Make sure no rain or water splash leaks into the equipment.</b><br>Fire or electrical shock can result if water leaks into the equipment.                      |
|               | <b>Immediately turn off the power at the switchboard if water leaks into the equipment.</b><br>Continued use of the equipment can cause fire or electrical shock. |

### Warning Label

A warning label is attached to the equipment. Do not remove the label. If the label is missing or damaged, contact a FURUNO agent or dealer about replacement.

## Safety instructions for the installer

|  <b>WARNING</b>   |  |                  |                  |                  |        |        |        |        |        |
|--|--|------------------|------------------|------------------|--------|--------|--------|--------|--------|
|                   | <b>Turn off the power at the switch-board before beginning the installation.</b><br>Turn off the power to prevent electrical shock.  |                  |                  |                  |        |        |        |        |        |
|                 | <b>Make sure the installation site is not subject to water spray.</b><br>Fire or electrical shock can result if water leaks into the equipment.  |                  |                  |                  |        |        |        |        |        |
|  <b>CAUTION</b> |  |                  |                  |                  |        |        |        |        |        |
|                 | <b>Observe the following compass safe distances to prevent interference to the instruments:</b>  |                  |                  |                  |        |        |        |        |        |
|  | <table border="1"> <thead> <tr> <th></th> <th>Standard compass</th> <th>Steering compass</th> </tr> </thead> <tbody> <tr> <td>FI-504</td> <td rowspan="2">0.35 m</td> <td>0.30 m</td> </tr> <tr> <td>FI-507</td> <td>0.25 m</td> </tr> </tbody> </table> |                  | Standard compass | Steering compass | FI-504 | 0.35 m | 0.30 m | FI-507 | 0.25 m |
|  | Standard compass   | Steering compass |                  |                  |        |        |        |        |        |
| FI-504   | 0.35 m   | 0.30 m           |                  |                  |        |        |        |        |        |
| FI-507   |  | 0.25 m           |                  |                  |        |        |        |        |        |



# TABLE OF CONTENTS

---

**FOREWORD** ..... **iv**

**SYSTEM CONFIGURATION** ..... **v**

**1. OPERATION** ..... **1**

- 1.1 Operating Controls, Display Layout..... 1
- 1.2 Turning the Power On/Off ..... 2
- 1.3 Adjusting Brilliance and Contrast ..... 2
- 1.4 Selecting a Display ..... 3
- 1.5 Selecting Apparent or True Wind Angle, Wind Speed..... 8
- 1.6 Resetting Counters and Indications ..... 8
- 1.7 Alarms ..... 9
- 1.8 Timers ..... 11

**2. MAINTENANCE, TROUBLESHOOTING** ..... **13**

- 2.1 Preventive Maintenance..... 13
- 2.2 Troubleshooting..... 14

**3. INSTALLATION** ..... **15**

- 3.1 Equipment Lists..... 15
- 3.2 Mounting..... 16
- 3.3 Wiring ..... 18
- 3.4 Setting Up..... 21

**SPECIFICATIONS** ..... **SP-1**

**PACKING LIST** ..... **A-1**

**OUTLINE DRAWINGS**..... **D-1**

**INTERCONNECTION DIAGRAM** ..... **S-1**

# FOREWORD

---

## A Word to the Owner of the FI-504, FI-507

Congratulations on your choice of the FURUNO FI-504 Multi/FI-507 Multi XL displays, members of the FI-50 series of marine instruments. We are confident you will see why the FURUNO name has become synonymous with quality and reliability.

For over 60 years FURUNO Electric Company has enjoyed an enviable reputation for quality marine electronics equipment. This dedication to excellence is furthered by our extensive global network of agents and dealers.

This equipment is designed and constructed to meet the rigorous demands of the marine environment. However, no machine can perform its intended function unless operated and maintained properly. Please carefully read and follow the recommended procedures for operation and maintenance.

Thank you for considering and purchasing FURUNO equipment.

## Features

The FI-504 Multi/FI-507 Multi XL displays provide heading, environment, autopilot, engine, depth, speed, and wind information, all on a high quality, backlit LCD. The sturdy weather-proof case is built to stand up to even the harshest of environments.


The main features are

- Eight varieties of displays: heading, environment, autopilot, engine, depth, speed, timer, and wind.
- Four levels of backlighting including off.
- Timers: Stopwatch and count-down
- Depth alarms: Shallow alarm, Deep alarm
- Anchor alarms: Shallow alarm, Deep alarm
- Voltage alarm monitors power source voltage
- Wind alarms: High apparent wind angle, Low apparent wind angle, Max. true wind speed, Low true wind speed
- Speed indications: Max. STW, Average STW, SOG, Max. SOG, Average SOG, Wind speed, Max. true wind speed
- Log indication from 0 to 99,999 nm
- Resettable trip counter, from 0 to 999 nm

# SYSTEM CONFIGURATION

---


## Standalone configuration



**NOTICE:** Turn on the terminal resistor in the instrument when connecting an NMEA 2000 sensor or CAN bus device. For the procedure, see the section on setting up, in the installation chapter.

SYSTEM CONFIGURATION

CAN bus network



**NOTICE:** Turn on the terminal resistor in the terminator of the CAN bus network.




# 1. OPERATION

Provided applicable sensors are connected, the FI-504/FI-507 provides the following information, all on a backlit LCD:

- Depth
- Speed
- Heading
- Environment data
- Autopilot (rudder)
- Engine
- Wind
- Timers
- Navigation data

## 1.1 Operating Controls, Display Layout




| Key name     | Function  |
|--------------|---|
| SELECT/CLEAR | <ul style="list-style-type: none"> <li>• Select menu option.</li> <li>• Silence alarm.</li> <li>• Clear data.</li> <li>• Reset counters and indications.</li> <li>• Increment value.</li> </ul> |
| APP/TRUE     | <ul style="list-style-type: none"> <li>• Select aparent or true (wind) alternately.</li> <li>• Decrement value.</li> </ul>  |
| MODE         | Select a display.   |
| DISP key     | <ul style="list-style-type: none"> <li>• Turn on power.</li> <li>• Select a display category.</li> </ul>  |

**Note:** The example screens shown in this manual are taken from the FI-504. The screens from the FI-507 may be different.

## 1.2 Turning the Power On/Off

**To power the instrument,** press the **DISP** key. All LCD segments go on and off and then the last-used display appears.


**To power off the instrument,** press the **DISP** and **MODE** keys together (about 7-10 seconds). The timer appears and counts down from three seconds to one second, and then the power goes off.



*Power OFF sequence*


## 1.3 Adjusting Brilliance and Contrast

1. Press the **DISP** and **MODE** keys together. The display for adjustment of brilliance appears, with current brilliance setting flashing.



2. Within seven seconds of completing step 1, press the **APP/TRUE** key to lower the brilliance, or the **SELECT/CLEAR** key to raise it.

3. Press the **DISP** and **MODE** keys together. The display for adjustment of contrast appears, with current contrast setting flashing.




4. Within seven seconds of completing step 3, press the **APP/TRUE** key to lower the contrast, or the **SELECT/CLEAR** key to raise it.

5. Press the **DISP** and **MODE** keys together to save the settings and restore normal operation.

The brilliance and contrast will be the same on all units which are synchronized. (For how to synchronize units, see page 26.)

## 1.4 Selecting a Display







Use the **DISP** key to select a display category. Select desired display with the **MODE** key.



1. OPERATION

1.4.1 Display description

Depth category

| Display title        | Indication  | Function   |
|----------------------|---|--|
| Current depth        | DPTH  | Current depth, in meters, feet or fathoms.   |
| Shallow alarm        |  SHALLOW   | Set shallow depth alarm. Audio and visual alarms are released when the depth is lower than the threshold value.  |
| Deep alarm           |  DEEP  | Set deep depth alarm. Audio and visual alarms are released when the depth is higher than the threshold value.    |
| Shallow anchor alarm |   SHALLOW | Set shallow anchor alarm. Audio and visual alarms are released when the depth is lower than the threshold value. |
| Deep anchor alarm    |   DEEP    | Set deep anchor alarm. Audio and visual alarms are released when the depth is higher than the threshold value.   |





Speed category

| Display title   | Indication | Function  |
|-----------------|------------|---|
| Boat speed      | SPD        | Boat speed, in knots (kt), miles per hour (MPH) or kilometers per hour (KMH).                                   |
| Maximum STW     | MAX SPD    | Maximum boat speed, in knots (kt), miles per hour (MPH) or kilometers per hour (KMH).                           |
| Average STW     | AVG SPD    | Average boat speed, in knots (kt), miles per hour (MPH) or kilometers per hour (KMH).                           |
| SOG             | SOG        | Speed over ground, in knots (kt), miles per hour (MPH) or kilometers per hour (KMH).                            |
| Maximum SOG     | MAX SOG    | Maximum speed over ground, in knots (kt), miles per hour (MPH) or kilometers per hour (KMH).                    |
| Average SOG     | AVG SOG    | Average speed over ground, in knots (kt), miles per hour (MPH) or kilometers per hour (KMH).                    |
| VMG to windward | VMG        | Velocity made good to windward, in knots (kt), miles per hour (MPH) or kilometers per hour (KMH).               |
| Log             | LOG        | Log distance (total distance run), in nautical miles, (NM) kilometers (KM) or statute miles (SM).               |
| Trip            | TRIP       | Trip distance (distance run between two points), in nautical miles (NM), kilometers (KM) or statute miles (SM). |

**Timer category**

| Display title      | Indication | Function            |
|--------------------|------------|---------------------|
| Count up timer     | UP         | Count-up timer.     |
| Count down timer 1 | DOWN 1     | Count-down timer 1. |
| Count down timer   | DOWN 2     | Count-down timer 2. |

**Wind category**

| Display title                  | Indication   | Function  |
|--------------------------------|--|---|
| Wind speed                     | APP (or TRUE)  | Wind speed, in knots or meters/second.  |
| Maximum true wind speed        | MAX TRUE   | Maximum true wind speed.  |
| Maximum true wind speed alarm  |  MAX TRUE | Set maximum true wind speed alarm. Audio and visual alarms are released when the wind speed goes higher than the threshold value.               |
| Low true wind speed alarm      |  TRUE LO  | Set low true wind speed alarm. Audio and visual alarms are released when the wind speed goes lower than the threshold value.                    |
| Wind angle                     | APP (or TRUE)  | Apparent (or true) wind angle, in degrees.  |
| High apparent wind angle alarm |  APP HI   | Set high apparent wind angle alarm. Audio and visual alarms are released when the wind angle at starboard goes higher than the threshold value. |
| Low apparent wind angle alarm  |  APP LO | Set low apparent wind angle alarm. Audio and visual alarms are released when the wind angle at port goes lower than the threshold value.        |
| Beaufort wind speed            | BFT  | Beaufort wind speed. Beaufort speeds up to 12 are shown. See the table below for Beaufort no. and wind speed.                                   |
| Ground wind angle              | GWIND  | Angle of wind over ground, in degrees. Bearing reference in Magnetic (MAG) or True (TRUE).  |

**Beaufort no. and wind speed**

| Beaufort no. | Wind speed |           | Beaufort no. | Wind speed |           |
|--------------|------------|-----------|--------------|------------|-----------|
|              | kt         | m/s       |              | kt         | m/s       |
| 0            | 0          | 0-0.2     | 7            | 28-33      | 14.4-17.4 |
| 1            | 1-3        | 0.5-2.0   | 8            | 34-40      | 17.5-21.0 |
| 2            | 4-6        | 2.1-3.5   | 9            | 41-47      | 21.1-24.6 |
| 3            | 7-10       | 3.6-5.6   | 10           | 48-55      | 24.7-28.8 |
| 4            | 11-16      | 5.7-8.6   | 11           | 56-63      | 28.9-32.6 |
| 5            | 17-21      | 8.7-11.2  | 12           | 64         | 32.7-32.9 |
| 6            | 22-27      | 11.3-14.3 |              |            |           |

1. OPERATION


**Heading category**

| <b>Display title</b> | <b>Indication</b> | <b>Function</b>  |
|----------------------|-------------------|--|
| Current heading      | HDG               | Heading, in degrees. Bearing reference in Magnetic (MAG) or True (TRUE).                           |
| Average heading      | AVG HDG           | Average heading, in degrees. Bearing reference in Magnetic (MAG) or True (TRUE).                   |
| Heading on next tack | TACK              | Heading on next tack, in degrees true (fixed). Bearing reference in Magnetic (MAG) or True (TRUE). |
| Course over ground   | COG               | Course over ground, in degrees. Bearing reference in Magnetic (MAG) or True (TRUE).                |
| Course made good     | CMG               | Course made good, in degrees. Bearing reference in Magnetic (MAG) or True (TRUE).                  |
| Distance made good   | DMG               | Distance made good, in kilometers (km), nautical miles (nm) or statute miles (sm).                 |

**Navigation category**

| <b>Display title</b> | <b>Indication</b> | <b>Function</b>  |
|----------------------|-------------------|--|
| Bearing to waypoint  | BTW               | Bearing to waypoint, in degrees. Bearing reference of Magnetic (MAG) or True (TRUE)  |
| Distance to waypoint | DTW               | Distance to waypoint, in kilometers (KM), nautical miles (NM) or statute miles (SM). |
| Cross track error    | XTE               | Cross-track error, in kilometers (KM), nautical miles (NM) or statute miles (SM).    |
| Waypoint number/name | WPT               | Waypoint number and name are shown.  |
| Latitude             | LAT               | Position in latitude.  |
| Longitude            | LON               | Position in longitude.   |
| Course over ground   | COG               | Course over ground, in degrees. Bearing reference in Magnetic (MAG) or True (TRUE).  |
| Speed over ground    | SOG               | Speed over ground, in knots (KT), miles per hour (MPH) or kilometers per hour (KMH). |
| Satellites tracked   | GPS SAT           | GPS satellites tracked.  |
| Roll                 | ROLL              | Ship's roll, in degrees.   |
| Pitch                | PITCH             | Ship's pitch, in degrees.  |

**Environment category**

| Display title                 | Indication   | Function  |
|-------------------------------|--|---|
| Battery voltage               | VOLTS  | Battery voltage.  |
| Minimum battery voltage alarm |  VOLTS LO | Set low battery voltage alarm. Audio and visual alarms are released when the battery voltage goes lower than the threshold value. |
| Time                          | -  | Current time, in 12-hour or 24-hour format.   |
| Date                          | -  | Current date.   |
| Water temperature             | WATER  | Water temperature, in °C or °F.   |
| Air temperature               | AIR  | Air temperature, in °C or °F.   |
| Air pressure                  | PRE  | Air pressure, in Hectopascal.   |
| Humidity                      | HUMID  | Relative humidity, in percentage.   |
| Wind chill temperature        | CHILL  | Wind chill temperature, in °C or °F.  |
| Dew point                     | DEW  | Dew point, in °C or °F.   |

**Autopilot category**

| Display title | Indication | Function   |
|---------------|------------|--|
| Rudder angle  | RUDDER     | Rudder angle, in degrees either P(ort) or S(tarboard). |

**Engine category**

| Display title  | Indication | Function   |
|----------------|------------|--|
| Trip fuel used | TOTAL      | Total fuel consumption, in liters or gallons.                                |
| Fuel rate      | RTE (L/H)  | Amount of fuel consumed in hour, in liters/hour (L/H) or gallons/hour (G/H). |
| Engine RPM     | RPM        | Engine speed per minute.   |

**Note:** In case of multiple engines, the data of desired engine number (max. eight, E0-E7) can be selected with the **SELECT/CLEAR** key.

***Scrolling speed and scrolling direction***

Display scrolling speed and direction can be changed by the length of key push.

**Short push:** Scroll in forward order.


**Medium push:** Go back one display. Several beeps sound and then the previous display appears.

**Hold down:** Rapid scrolling, in forward direction. Several beeps sound and then speed is changed.

## 1.5 Selecting Apparent or True Wind Angle, Wind Speed

You can show wind angle and wind speed in apparent or true wind. The **apparent wind** is the actual flow of air acting upon a sail, or the wind as it appears to the sailor. **True wind** is the wind seen by a stationary observer in velocity and direction.

With a wind angle or wind speed indication displayed, press the **APP/TRUE** key to change the wind angle or wind speed to apparent and true alternately. A beep sounds after the change is completed. (Wind angle and wind speed displays are mutually changed.) True wind requires boat speed input. If there is no speed input three dashes appear.



## 1.6 Resetting Counters and Indications

You can reset the following counters and indications:

- Trip
- Course made good
- Distance made good
- Average speed
- Average SOG
- Maximum speed
- Maximum SOG
- Average heading
- Maximum true wind speed










Select the applicable display and press and hold down the **SELECT/CLEAR** key. A short beep sounds, the counter or indication flashes twice and then a long beep sounds to indicate that resetting is completed.



## 1.7 Alarms

There nine conditions which trigger audio and visual alarms: Shallow alarm, Deep alarm, Shallow anchor alarm, Deep anchor alarm, Max. true wind speed alarm, Low true wind speed alarm, High apparent wind angle alarm, low apparent wind angle alarm, and low battery voltage alarm.

1. Use the **DISP** and **MODE** keys to select desired alarm page, referring to the illustration below for alarm location.

| Display category | Available alarms  |  |  |  |
|------------------|---|--|--|--|
| DEPTH            | <br>Shallow alarm              | <br>Deep alarm                | <br>Shallow anchor alarm           | <br>Deep anchor alarm             |
| WIND             | <br>Max. true wind speed alarm | <br>Low true wind speed alarm | <br>High apparent wind angle alarm | <br>Low apparent wind angle alarm |
| ENVIRONMENT      | <br>Low voltage alarm        |  |  |  |

\*S (Starboard) or P (Port)


### Alarm description

| Alarm                          | Alarms released when;                                | Setting range                           |
|--------------------------------|--|---|
| Shallow alarm                  | depth is shallower than this threshold.              | 0.0-303 m                               |
| Deep alarm                     | depth is deeper than this threshold.                 | 0.1-304 m                               |
| Shallow anchor alarm           | anchor depth is shallower than this threshold.       | depth is shallower than this threshold. |
| Deep anchor alarm              | anchor depth is greater than this threshold.         | depth is deeper than this threshold.    |
| Max. true wind speed alarm     | max. true wind speed is greater than this threshold. | 0.1-999 kts                             |
| Low true wind speed alarm      | true wind speed is lower than this threshold.        | 0-998 kts                               |
| High apparent wind angle alarm | apparent wind angle is higher than this threshold.   | S0°-S179° (High)<br>S180°-P1° (Low)     |
| Low apparent wind angle alarm  | apparent wind angle is lower than this threshold.    | (S=Starboard, P=Port)                   |

*Alarm description*

| Alarm                     | Alarms released when;                         | Setting range    |
|---------------------------|---|------------------|
| Low battery voltage alarm | battery voltage is lower than this threshold. | 5.0 - 20.0 volts |

2. If the selected alarm page shows “Off,” press and hold down the **SELECT/CLEAR** key until an alarm setting appears.
3. Press the **APP/TRUE** and **SELECT/CLEAR** keys together to enable adjustment. The alarm setting starts flashing.
4. Press the **APP/TRUE** key to lower the setting; the **SELECT/CLEAR** key to raise it.  
**Note:** A low alarm cannot be set higher than its affiliated high (max.) alarm.
5. Press the **APP/TRUE** and **SELECT/CLEAR** keys together to confirm setting and restore normal operation.

When an alarm is violated, the buzzer sounds and the alarm icon (  ) flashes. You can silence the buzzer with the **SELECT/CLEAR** key. The icon continues flashing until the offending alarm is disabled.

While the icon is flashing you can switch between alarm display and current display alternately by pressing the **DISP** and **SELECT/CLEAR** keys together.

## 1.8 Timers

Three timers are provided:

- Count-up timer (stopwatch)
- Count-down timer (two provided)

Time is displayed in seconds or minutes, depending on counter values.

Once you have set a timer, you can leave that page and select any other display. The counter continues to run in the background.

### Count-up timer

The count-up timer functions like a stop watch, counting time upward, to 99 hours, 99 minutes and 59 seconds.

### Count-down timers

The two count-down timers count down from a time between 15 minutes and one minute. When these timers have counted down to zero, they then start counting up. The timers beep at preset intervals to alert you to specific points in time.


- Two beeps every minute
- Three beeps at the start of the last 30 seconds
- One beep/second for each of the last 10 seconds
- Two-second beep at zero

### How to set the timers


1. Press the **MODE** key to show the desired timer display.



Count-up  
timer



Count-down  
timer 1



Count-down  
timer 2

2. Do one of the following depending on timer type selected:

#### **Count-up timer:**

Press the **SELECT/CLEAR** key to start the timer. A long beep sounds and the timer starts counting upward.

#### **Count-down timer:**

To start the timer from the time shown, press the **SELECT/CLEAR** key. To set a different start time, press the **APP/TRUE** and **SELECT/CLEAR** keys together to enable adjustment. Use the **APP/TRUE** key to lower the value; **SELECT/CLEAR** key to raise it. Press the **APP/TRUE** and **SELECT/CLEAR** keys together to confirm setting. Press the **SELECT/CLEAR** key to start the timer.

## 1. OPERATION


**To stop or restart the timer**, press the **SELECT/CLEAR** key momentarily. A short beep sounds when the timer is stopped or restarted.

**To stop and reset the timer to start value**, press the **SELECT/CLEAR** key until you hear a long beep. The timer is stopped and reset to start value.

The timer settings are reflected on any timer-equipped instrument in the network which is set up for synchronization.

# 2. MAINTENANCE, TROUBLESHOOTING

This chapter provides the information necessary for keeping your equipment in good working order.

|   |  |
|---|--|
| <b>⚠ WARNING</b>  |  |
|  | <p><b>Do not open the equipment.</b></p> <p>Only qualified personnel should work inside the equipment.</p> |

## 2.1 Preventive Maintenance

Following the recommended procedures below will help maintain performance.

| Check item | Check point  | Remedy  |
|------------|--|---|
| Cabling    | Check that all cabling is securely fastened and is free of rust and corrosion. | Reconnect if necessary. Replace if damaged.   |
| Cabinet    | Dust on cabinet  | Remove dust with a soft, lint-free cloth. <div style="border: 1px solid black; padding: 10px; margin-top: 10px;"> <p style="text-align: center;"><b>NOTICE</b></p> <p><b>Do not apply paint, anti-corrosive sealant or contact spray to coating or plastic parts of the equipment.</b></p> <p>Those items contain organic solvents that can damage coating and plastic parts, especially plastic connectors.</p> </div> |

## 2.2 Troubleshooting

If you feel the equipment is not functioning properly, follow the procedures in the table below to try to restore normal operation. If normal operation cannot be restored, do not attempt to check inside the cabinet. There are no user-serviceable parts inside.

### Troubleshooting

| <b>Problem</b>                      | <b>Possible cause</b>  | <b>Remedy</b>  |
|-------------------------------------|--|--|
| Display is blank. Panel is not lit. | <ul style="list-style-type: none"> <li>• Power supply</li> <li>• Cabling disconnected or damaged.</li> </ul>   | <ul style="list-style-type: none"> <li>• Check power supply.</li> <li>• Check cabling.</li> </ul>  |
| Power is on but no or some data.    | <ul style="list-style-type: none"> <li>• Sensor is turned off.</li> <li>• Cable from sensor is disconnected or damaged.</li> </ul>   | <ul style="list-style-type: none"> <li>• Turn on sensor.</li> <li>• Check cabling.</li> </ul>  |
| Inaccurate data                     | <ul style="list-style-type: none"> <li>• Electromagnetic field generating equipment is in operation.</li> <li>• Cabling from sensor is damaged.</li> <li>• Sensor is improperly aligned (where applicable).</li> </ul> | <ul style="list-style-type: none"> <li>• Turn off all electromagnetic field generating equipment. Turn them on and off one by one. Check the display. Relocate offending equipment or this instrument as appropriate.</li> <li>• Check cabling.</li> <li>• Check installation. If installation is proper, an offset may be applied to certain data. For details, see section 1.7.</li> </ul> |

# 3. INSTALLATION

## NOTICE

**Do not apply paint, anti-corrosive sealant or contact spray to coating or plastic parts of the equipment.**

Those items contain organic solvents that can damage coating and plastic parts, especially plastic connectors.

## 3.1 Equipment Lists

### Standard supply

(FI-504)

| Name                   | Type       | Code No.    | Qty   | Remarks  |
|------------------------|------------|-------------|-------|--|
| Display Unit           | FI-504     | -           | 1     |  |
| Installation Materials | CP26-00600 | 000-011-744 | 1 set | See packing list at end of manual for details. |

(FI-507)

| Name                   | Type       | Code No.    | Qty   | Remarks  |
|------------------------|------------|-------------|-------|--|
| Display Unit           | FI-507     | -           | 1     |  |
| Installation Materials | CP26-00800 | 000-015-730 | 1 set | See packing list at end of manual for details. |

### Optional supply


| Name            | Type             | Code No.       | Qty   | Remarks    |
|-----------------|------------------|----------------|-------|------------|
| Cable Assy.     | FI-50-DROP       | 000-166-945-10 | 1     |            |
|                 | FI-50-CHAIN-0.3M | 000-166-949-10 | 1     |            |
|                 | FI-50-CHAIN-5M   | 000-166-951-10 | 1     |            |
|                 | FI-50-CHAIN-1M   | 000-166-950-10 | 1     |            |
|                 | FI-50-CHAIN-10M  | 000-166-952-10 | 1     |            |
|                 | FI-50-CHAIN-20M  | 000-166-953-10 | 1     |            |
| Flush Mount Kit | FI-50-FLUSH-KIT  | 000-010-619    | 1 set | For FI-504 |
|                 | FI-507-FLUSH-KIT | 000-015-722    |       | For FI-507 |
| Junction Box    | FI-5002          | 000-010-765    | 1 set |            |
| Smart Sensor    | DST-800          | 000-168-850-10 | 1     |            |

## 3.2 Mounting

The display unit can be installed two ways: surface mount (fixed at front panel or fixed from rear panel) and flush mount (optional kit required). This section covers surface mounting. For flush mounting, see the flush mounting instructions, issued separately.

### **Surface mount 1: Fix instrument from front panel**

1. Using the applicable template at the back of this manual, open a mounting hole in the installation site.
2. Detach the front panel together with the keypad assy. Attach sponge (supplied) to rear of display unit.
3. Set the display unit to the mounting hole, and fix it with four self-tapping screws (3x20, supplied).
4. Attach the front panel and keypad assy. to the display unit.




(ex. FI-504)




**Surface mount 2: Fix instrument from rear panel**

1. Using the applicable template at the back of this manual, open a mounting hole in the installation site.
2. Insert studs (M3x40, 2 pcs. (FI-504) or 4 pcs. (FI-507), supplied) in the holes shown below. (Use only the studs supplied.)

*Display unit, rear view*

3. Set the display unit to the mounting hole, inserting studs through respective holes. Fix the display unit with spring washers, flat washers and wing nuts (M3, supplied).




### 3.3 Wiring


For detailed information about CAN bus wiring, see “Furuno CAN bus Network Design Guide (TIE-00170-\*) on Tech-Net.

#### 3.3.1 Standalone configuration

For standalone configuration the junction box is not necessary; connect the instrument directly to the power supply.




#### 3.3.2 Multi-instrument configuration



The total length of drop cables and backbone cables must be within 80 m.


### **Junction box (option)**

The junction box is required when connecting CAN bus network. This section covers wiring of the junction box. For how to mount the junction box, see its installation instructions, issued separately.




Fix cable with cable tie (supplied).

CH3 DROP - CH5 DROP and BACKBONE are socket-and-plug-type terminal blocks. Detach plug to connect wiring to it, by rocking it back and forth with your fingers. Remove approx. 6 mm of the sheath from the end of wires and twist wires. Loosen fixing screw in the plug, insert wire into hole and tighten fixing screw. Set plug to socket.



*How to fabricate cable*




*How to insert wire*


**Terminal resistor**

The illustration below show various system configurations and what units to activate the terminal resistor.


**Smart sensor+FI-50x**




**Multiple FI-50 series instruments, FI-5002, drop cabling**




**Multiple FI-50 series instruments, FI-5002**




**Multiple FI-50 series instruments, multiple FI-5002**




**Multiple FI-50 series instruments, FI-5002, smart sensor**



**Multiple FI-50 series instruments, FI-5002, heading sensor, smart sensor**




**Multiple FI-50 series instruments, FI-5002, NMEA 2000, CAN bus sensors**



• = Terminal resistor ON

Turn on the terminal resistor in the junction box when the FURUNO CAN bus and/or NMEA 2000 sensor(s) connected to it do not have a terminal resistor.



For how to turn on the terminal resistor in a FI-50 series instrument, see paragraph 3.4.2 “Setup2 menu”.

## 3.4 Setting Up

Your instrument is pre-programmed with factory default settings, which may or may not be suited to your vessel. Therefore, it is necessary to initialize the instrument for use with your vessel. This should be done immediately after completion of the installation.


Two sets of setup menus are provided: setup1 and setup2. The setup1 menu provides system parameters and the setup2 menu has user settings.

### 3.4.1 Setup1 menu

The setup1 menu contains system parameters which optimize the instrument for use on your vessel. Follow the procedure below to access and set parameters.

1. Press the **APP/TRUE** and **SELECT/CLEAR** keys momentarily to enable the setup1 menu. The Depth unit selection screen appears, with the depth unit flashing. (See the illustration on the next page.)
2. Use the **DISP** key to select a menu item. Each press of the key changes the menu item in the sequence shown in the illustration on the next page.

### 3. INSTALLATION



3. Use the **APP/TRUE** or **SELECT/CLEAR** key to set value or select option.









**VMG** key: Decrement value

**SELECT/CLEAR** key: Increment value or select option.

4. To continue, press the **DISP** key to select another menu item.

5. To save settings and restore normal operation, press the **APP/TRUE** and **SELECT/CLEAR** keys together.

Setup1 menu items









| Display   | Function  | Setting range or options                                    | Default setting |
|---|---|---|-----------------|
|    | Select depth unit.  | M (Meter),<br>FT (Feet)                                     | M               |
|    | Set depth offset.   | -99 - +99   | 0.0             |
|    | Lock/unlock shallow alarm setting.  | ON, OFF   | OFF             |
|   | Set depth response. The lower the setting the faster the response to change in depth. | 0 - 12  | 3               |
|  | Select speed unit.  | KT (Knot),<br>MPH (Miles/Hour),<br>KMH (Kilometers/Hour)    | KT              |
|  | Select speed resolution. Select number of places to show after decimal point.         | 0.01, 0.1   | 0.01            |
|  | Set speed adjustment.<br>(STW only)   | 0.30- 2.50  | 1.00            |
|  | Select log unit.  | NM (Nautical Mile),<br>SM (Statute Mile),<br>KM (Kilometer) | NM              |

Setup1 menu items

| Display  | Function   | Setting range or options                    | Default setting |
|--|--|---|-----------------|
| <div style="border: 1px solid black; padding: 5px; width: fit-content;"> <b>SPD RES</b><br/> <small>CAL</small><br/> <b>0</b> </div>   | Set speed response. The lower the setting the faster the response to change in speed.            | 0 - 12                                      | 0               |
| <div style="border: 1px solid black; padding: 5px; width: fit-content;"> <b>SOG RES</b><br/> <small>CAL</small><br/> <b>0</b> </div>   | Set SOG response. The lower the setting the faster the response to change in speed over ground.  | 0 - 12                                      | 0               |
| <div style="border: 1px solid black; padding: 5px; width: fit-content;"> <b>VMG RES</b><br/> <small>CAL</small><br/> <b>3</b> </div>   | Set VMG response. The lower the setting the faster the response to change in velocity made good. | 0 - 12                                      | 3               |
| <div style="border: 1px solid black; padding: 5px; width: fit-content;"> <b>*TIMER</b><br/> <small>CAL</small><br/> <b>On</b> </div>   | Enable/disable the timer alarm's audio alarm.  | ON, OFF                                     | ON              |
| <div style="border: 1px solid black; padding: 5px; width: fit-content;"> <b>WIND</b><br/> <small>CAL</small><br/> <b>F</b> </div>      | Select source of wind data. Select "r" for second unit.  | F: For FI-5001 (Furuno Sensor), r: repeater | F               |
| <div style="border: 1px solid black; padding: 5px; width: fit-content;"> <b>WIND KT</b><br/> <small>CAL</small> </div>                 | Select wind unit.  | KT (Knot),<br>M/S (Meters/Second)           | KT              |
| <div style="border: 1px solid black; padding: 5px; width: fit-content;"> <b>WINDADJ</b><br/> <small>CAL</small><br/> <b>1.0</b> </div> | Set wind speed adjustment.   | 0.3 - 2.5                                   | 1.0             |
| <div style="border: 1px solid black; padding: 5px; width: fit-content;"> <b>ANGLE S</b><br/> <small>CAL</small><br/> <b>0</b> </div>   | Set wind angle offset.   | S 0° - 180°<br>P 1° - 179°                  | 0               |
| <div style="border: 1px solid black; padding: 5px; width: fit-content;"> <b>WSPDRES</b><br/> <small>CAL</small><br/> <b>3</b> </div>   | Set wind speed response. The higher the setting the faster the response to change in wind speed. | 0 - 12                                      | 3               |




Setup1 menu items

| Display   | Function  | Setting range or options       | Default setting |
|---|---|--------------------------------|-----------------|
|    | Select true or magnetic bearing.  | MAG (Magnetic),<br>TRU (True)  | MAG             |
|    | Select heading type to display when activating locked heading.                            | LOC (Locked),<br>CUr (Current) | LOC             |
|    | Set heading response. The lower the setting the faster the response to change in heading. | 0 - 12                         | 0               |
|   | Select time format.   | 12, 24 (hour)                  | 12              |
|  | Use local time. Enter time difference between local time and GMT to use local time.       | -12 - +12                      | 0               |
|  | Select water temperature unit.  | °C, °F                         | °C              |
|  | Set water temperature offset.   | -99 - +99                      | 0               |
|  | Select fuel unit.   | L (Liter),<br>G (Gallon)       | L               |

### 3.4.2 Setup2 menu











The setup 2 menu contains user settings which once preset do not require frequent adjustment.

1. Press and hold down the **APP/TRUE** and **SELECT/CLEAR** keys together (about 5-6 seconds) to enable the user settings menu. The software version of CPU1 appears. (See the illustration below.)
2. Press the **DISP** key to choose menu item. Each press of the key changes the menu item in the sequence shown below.












3. Use the **SELECT/CLEAR** key to select setting.
4. To continue, press the **DISP** key to select another item.
5. To save settings and restore normal operation, press the **APP/TRUE** and **SELECT/CLEAR** keys together.

Setup2 menu items

| Display   | Function   | Setting range or options   | Default setting |
|---|--|--|-----------------|
|    | Software version of CPU1.<br>X=program no. and<br>xxxx=program version no. | -  | -               |
|    | Software version of CPU2.<br>X=program no. and<br>xxxx=program version no. | -  | -               |
|    | Turn key beep on/off.  | ON, OFF  | ON              |
|    | Auto brilliance on/off.  | ON, OFF  | ON              |
|    | Enable/disable alternating displays.                                       | OFF<br>1: Depth/boat spd<br>2: Boat spd/water temp.<br>3: Depth/water temp.<br>4: Depth/boat spd/water temp.<br>5: Roll/pitch<br>6: Latitude/Longitude   | OFF             |
|  | Enable/disable access to the setup1 menu.                                  | ON, OFF  | ON              |
|  | Turn the terminal resistor on/off.   | ON, OFF  | OFF             |
|  | Turn on/off synchronization of FI-50 series instruments.                   | ON:<br>Synchronize FI-50 instruments having this setting.<br>OFF:<br>Turn off synchronization.<br>A:<br>Synchronize FI-50 instruments having this setting.<br>b:<br>Synchronize FI-50 instruments having this setting. | ON              |
|  | Turn depth displays on/off.  | ON, OFF  | ON              |
|  | Turn speed displays on/off.  | ON, OFF  | ON              |

Setup2 menu items

| Display   | Function   | Setting range or options | Default setting |
|---|--|--------------------------|-----------------|
|    | Turn timer displays on/off.  | ON, OFF                  | ON              |
|    | Turn wind displays on/off.   | ON, OFF                  | ON              |
|    | Turn heading displays on/off.  | ON, OFF                  | ON              |
|    | Turn navigation displays on/off.   | ON, OFF                  | ON              |
|    | Turn environmental displays on/off.  | ON, OFF                  | ON              |
|   | Turn autopilot displays on/off.  | ON, OFF                  | ON              |
|  | Turn engine displays on/off.   | ON, OFF                  | ON              |
|  | Demo mode. To enable, press the <b>SELECT/CLEAR</b> key. Depth is shown. To disable and return to this menu, press and hold down the <b>SELECT/CLEAR</b> key.          | ON, OFF                  | OFF             |
|  | Restore factory defaults. To restore factory defaults, press and hold down the <b>SELECT/CLEAR</b> key to show ON. Press the key again. A beep sounds upon completion. | ON, OFF                  | OFF             |

## SPECIFICATIONS OF FI-504 MULTI

### 1 GENERAL

- |     |                   |   |
|-----|-------------------|---|
| 1.1 | Indication system | Segment LCD   |
| 1.2 | Brilliance        | 4 steps   |
| 1.3 | Contrast          | 3 steps   |
| 1.4 | Display Contents  | Depth, speed, wind speed, wind angle, timer, environmental information (water temperature, air temperature, air pressure, dewpoint, wind chill temperature), rudder angle |
| 1.5 | Number of Port    | CAN bus, 2 ports  |
| 1.6 | Mount Method      | Surface or flush mount  |

### 2 JUNCTION BOX (OPTION)

- |     |                    |   |
|-----|--------------------|---|
| 2.1 | Number of Port     | CAN bus Drop: 6 ports,<br>CAN bus Backbone: 2 ports |
| 2.2 | Circuit Protection | Reverse, short, over current                        |

### 3 POWER SUPPLY AND POWER CONSUMPTION

- |     |              |  |
|-----|--------------|--|
| 3.1 | Display Unit | 12 VDC, less than 0.1 A                    |
| 3.2 | Junction Box | 12 VDC, less than 1 A, max. 2A connectable |

### 4 ENVIRONMENTAL CONDITIONS

- |     |                           |  |
|-----|---------------------------|--|
| 4.1 | Useable Temperature Range | -15°C - +55°C  |
| 4.2 | Relative Humidity         | Less than 95% (+40°C)  |
| 4.3 | Waterproofing             |  |
|     | Display Unit              | IP56   |
|     | Junction Box              | IPX0   |
| 4.4 | Vibration                 | - 2 Hz-5 Hz and up to 13.2 Hz with an excursion of $\pm 1$ mm $\pm 10\%$ ( $7 \text{ m/s}^2$ maximum acceleration at 13.2 Hz);<br>- above 13.2 Hz and up to 100 Hz with a constant maximum acceleration of $7 \text{ m/s}^2$ |

### 5 COATING COLOR

- |     |              |      |
|-----|--------------|------|
| 5.1 | Display Unit | N2.5 |
| 5.2 | Junction Box | N2.5 |

## SPECIFICATIONS OF FI-507 MULTI XL

### 1 GENERAL

|     |                   |   |
|-----|-------------------|---|
| 1.1 | Indication system | Segment LCD   |
| 1.2 | Brilliance        | 4 steps   |
| 1.3 | Contrast          | 3 steps   |
| 1.4 | Display contents  | Depth, Ship's speed, Wind speed/angle, Date, Time, Bearing<br>Environmental information <sup>*1</sup> , Navigational information,<br>Rudder angle, Engine information <sup>*2</sup> |
| 1.5 | Number of port    | CAN bus: 2 port   |
| 1.6 | Mount method      | Surface or flush mount  |

\*1) Battery voltage, date, time, water temperature, air temperature, air pressure, humidity, wind chill temperature and dew point

\*2) Fuel consumption, fuel efficiency and engine speed

### 2 JUNCTION BOX

|     |                    |                                      |
|-----|--------------------|--------------------------------------|
| 2.1 | Number of port     | CAN bus drop: 6, CAN bus backbone: 2 |
| 2.2 | Circuit protection | Reverse, short, over current         |

### 3 POWER SUPPLY

|     |              |               |
|-----|--------------|---------------|
| 3.1 | Main unit    | 12 VDC: 0.1 A |
| 3.2 | Junction box | 12 VDC: 1 A   |

### 4 ENVIRONMENTAL CONDITION

|     |                      |  |
|-----|----------------------|--|
| 4.1 | Ambient temperature  | -15°C to +55°C   |
| 4.2 | Relative humidity    | 95% at 40°C  |
| 4.3 | Degree of protection |  |
|     | Main unit            | IP56   |
|     | Junction box         | IPX0   |
| 4.4 | Vibration            | - 2 Hz-5 Hz and up to 13.2 Hz with an excursion of<br>$\pm 1 \text{ mm} \pm 10\%$ ( $7 \text{ m/s}^2$ maximum acceleration at 13.2 Hz);<br>- above 13.2 Hz and up to 100 Hz with a constant<br>maximum acceleration of $7 \text{ m/s}^2$ |









### 5 COATING COLOR

|     |              |      |
|-----|--------------|------|
| 5.1 | Main unit    | N2.5 |
| 5.2 | Junction box | N2.5 |

# PACKING LIST FI-504

26AA-X-9860-2






1/1

| NAME               | OUTLINE   | DESCRIPTION/CODE No. | Q'TY |
|--------------------|---|----------------------|------|
| ユニット               |   |                      |      |
| 表示部                |    | FI-504               | 1    |
| MONITOR UNIT       |   | 000-011-745-00       |      |
| 工事材料               | INSTALLATION MATERIALS  | CP26-00600           |      |
| パネルリムーバ            |    | 19-028-3124-1        | 1    |
| PANEL REMOVER      |   | 100-340-471-10       |      |
| サフエスワントラストポンジ      |    | TZ7583002A0          | 1    |
| SPONGE             |   | 000-167-832-10       |      |
| ナハクツピソネジ 1シユ       |    | 3X20 SUS304          | 4    |
| SELF-TAPPING SCREW |   | 000-163-884-10       |      |
| ハネ座金               |    | M3 SUS304            | 2    |
| SPRING WASHER      |   | 000-167-404-10       |      |
| ミギキ丸平座金            |    | M3 SUS304            | 2    |
| FLAT WASHER        |   | 000-167-453-10       |      |
| 蝶ナット               |  | M3 SUS304            | 2    |
| WING NUT           |   | 000-167-826-10       |      |
| 寸切ボルト              |  | M3X40 SUS304         | 2    |
| BOLT               |   | 000-167-804-10       |      |

コード番号末尾の「\*\*」は、選択品の代表コードを表します。

CODE NUMBER ENDING WITH "\*\*" INDICATES THE CODE NUMBER OF REPRESENTATIVE MATERIAL.

(略図の寸法は、参考値です。DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

| NAME                      | OUTLINE   | DESCRIPTION/CODE No. | Q'TY |
|---------------------------|---|----------------------|------|
| ケーブル組品                    |  | FI-50-DROP           | 1    |
| CABLE ASSY.               |   | 000-166-945-11       |      |
| ケーブル組品0.3M                |  | FI-50-CHAIN-O.3M     | 1    |
| CABLE ASSY.               |   | 000-166-949-11       |      |
| 図書                        | DOCUMENT  |                      |      |
| 内部終端/設定                   |  | C72-00705-*          | 1    |
| INTERNAL RESISTOR SETTING |   | 000-168-501-1*       |      |
| 操作要領書                     |  | OS*-72690-*          | 1    |
| OPERATOR'S GUIDE          |   | 000-167-295-1*       | **   |
| 取扱説明書                     |  | OME-72690-*          | 1    |
| OPERATOR'S MANUAL         |   | 000-167-334-1*       |      |

型式/コード番号が2段の場合、下段より上段に代わる過渡期品であり、どちらかが入っています。なお、品質は変わりません。









TWO TYPES AND CODES MAY BE LISTED FOR AN ITEM. THE LOWER PRODUCT MAY BE SHIPPED IN PLACE OF THE UPPER PRODUCT. QUALITY IS THE SAME.






A-1

# PACKING LIST FI-507

26AA-X-9863-0

1/1

| NAME               | OUTLINE   | DESCRIPTION/CODE No. | Q'TY |
|--------------------|---|----------------------|------|
| ユニット               |   |                      |      |
| 表示部                |    | FI-507               | 1    |
| MONITOR UNIT       |   | 000-015-729-00       |      |
| <b>CP26-00800</b>  |   |                      |      |
| 工事材料               | <b>INSTALLATION MATERIALS</b>   |                      |      |
| ＋ハブタッピンネジ 1ｼｼ      |    | 3X20 SUS304          | 4    |
| SELF-TAPPING SCREW |   | 000-163-884-10       |      |
| Sマウントスポンジ XL       |    | TZ7583059A0          | 1    |
| SPONGE             |   | 000-170-617-10       |      |
| ケーブル組品             |    | FI-50-DROP           | 1    |
| CABLE ASSY.        |   | 000-166-945-11       |      |
| ケーブル組品0.3M         |    | FI-50-CHAIN-0.3M     | 1    |
| CABLE ASSY.        |   | 000-166-949-11       |      |
| パネルリムーバー           |    | 19-028-3124-1        | 1    |
| PANEL REMOVER      |   | 100-340-471-10       |      |
| バネ座金               |  | M3 SUS304            | 4    |
| SPRING WASHER      |   | 000-167-404-10       |      |
| ミカキ丸平座金            |  | M3 SUS304            | 4    |
| FLAT WASHER        |   | 000-167-453-10       |      |

| NAME                  | OUTLINE   | DESCRIPTION/CODE No. | Q'TY |
|-----------------------|---|----------------------|------|
| 寸切ボルト                 |  | M3X40 SUS304         | 4    |
| BOLT                  |   | 000-167-804-10       |      |
| 蝶ナット                  |  | M3 SUS304            | 4    |
| WING NUT              |   | 000-167-826-10       |      |
| <b>図書</b>             |   |                      |      |
| <b>DOCUMENT</b>       |   |                      |      |
| 取扱説明書 (英)             |  | OME-72690-*          | 1    |
| OPERATOR'S MANUAL     |   | 000-167-334-1*       |      |
| 操作要領書 (英)             |  | OSE-72770-*          | 1    |
| OPERATOR'S GUIDE (EN) |   | 000-170-641-1*       |      |
| 内部終端/設定               |  | C72-00705-*          | 1    |
| INTERNAL RESISTOR     |   | 000-168-501-1*       |      |

A-2

型式/コード番号が2段の場合、下段より上段に代わる過渡期品であり、どちらが入っています。なお、品質は変わりません。

TWO TYPES AND CODES MAY BE LISTED FOR AN ITEM. THE LOWER PRODUCT MAY BE SHIPPED IN PLACE OF THE UPPER PRODUCT. QUALITY IS THE SAME.

(略図の寸法は、参考値です。DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)




26AA-X-9863



表1 TABLE 1

| 寸法区分 (mm)<br>DIMENSION | 公差 (mm)<br>TOLERANCE |
|------------------------|----------------------|
| $L \leq 50$            | $\pm 1.5$            |
| $50 < L \leq 100$      | $\pm 2.5$            |
| $100 < L \leq 500$     | $\pm 3$              |

取付穴寸法図  
CUTOUT DIMENSIONS



注 記

- 1) 指定外の寸法公差は表1による。
- 2) #印寸法は最小サービスクリアランスとする。
- 3) 取付方法は次の2種類から選択する。  
 ◎: ナベタッピンネジ呼び径3×20を使用のこと。  
 ⊙: M3×40寸切りボルト、M3平座金/バネ座金/バネナットを使用のこと。

NOTE

1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.
2. # : MINIMUM SERVICE CLEARANCE.
3. SELECT FIXING METHOD FROM FOLLOWINGS;  
 ◎ : USE TAPPING SCREWS  $\phi 3 \times 20$ .  
 ⊙ : USE M3 STUD BOLT, P.W. / S.W. / WING NUT, SCREW LENGTH: 40.

|          |             |                                 |               |                            |
|----------|-------------|---------------------------------|---------------|----------------------------|
| DRAWN    | Sep. 27 '07 | I. YAMASAKI                     | TITLE         | FI-501/502/503/504/505/506 |
| CHECKED  | Sep. 27 '07 | I. TAKENO                       | 名称            | インストルメント (サーフェスマウント)       |
| APPROVED | Sep. 28 '07 | R. Esumi                        | 外寸図           |                            |
| SCALE    | 1/100       | 質量はケーブルを含まず。<br>MASS W/O CABLE. | NAME          | INSTRUMENT (SURFACE MOUNT) |
| DWG.No.  | C7266-G02-B | REF.No.                         | 26-001-102G-2 | OUTLINE DRAWING            |







表1 TABLE 1

| 寸法区分 (mm)<br>DIMENSION | 公差 (mm)<br>TOLERANCE |
|------------------------|----------------------|
| L ≤ 50                 | ±1.5                 |
| 50 < L ≤ 100           | ±2.5                 |
| 100 < L ≤ 500          | ±3                   |



注 記

- 1) 指定外の寸法公差は表1による。
- 2) 取付用ネジはナベタツ呼び径3×20を使用のこと。




NOTE

1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.
2. USE TAPPING SCREWS  $\phi 3 \times 20$  FOR FIXING THE UNIT.

|          |             |                        |               |                            |
|----------|-------------|------------------------|---------------|----------------------------|
| DRAWN    | Jul. 19 '07 | T. YAMASAKI            | TITLE         | FI-501/502/503/504/505/506 |
| CHECKED  | Jul. 19 '07 | T. TAKENO              | 名称            | インストルメント (フラッシュマウント)       |
| APPROVED | Jul. 24 '07 | R. Esumi               | 外寸図           |                            |
| SCALE    |             | MASS 0.3<br>±10%<br>kg | NAME          | INSTRUMENT (FLUSH MOUNT)   |
| DWG.No.  | C7266-G01-A | REF.No.                | 26-001-101G-0 | OUTLINE DRAWING            |

表1 TABLE 1

| 寸法区分 (mm)<br>DIMENSION | 公差 (mm)<br>TOLERANCE |
|------------------------|----------------------|
| L ≤ 50                 | ±1.5                 |
| 50 < L ≤ 100           | ±2.5                 |
| 100 < L ≤ 500          | ±3                   |



注 記

- 1) #印寸法は最小サービスマン間寸法とする。
- 2) 指定外の寸法公差は表1による。
- 3) 取付用ネジはトラスタップピンネジ呼び径4×20を使用のこと。

NOTE

1. # MINIMUM SERVICE CLEARANCE.
2. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.
3. USE TAPPING SCREWS  $\phi 4 \times 20$  FOR FIXING THE UNIT.

|          |             |             |               |                 |
|----------|-------------|-------------|---------------|-----------------|
| DRAWN    | Jul. 19 '07 | T. YAMASAKI | TITLE         | FI-5002         |
| CHECKED  | Jul. 19 '07 | I. TAKENO   | 名称            | ジャンクションボックス     |
| APPROVED | Jul. 24 '07 | R. Esumi    | 外寸図           |                 |
| SCALE    | 1/100       | 0.3 kg      | NAME          | JUNCTION BOX    |
| DWG.No.  | C7268-G01-A | REF.No.     | 26-001-103G-0 | OUTLINE DRAWING |




表1 TABLE 1

| 寸法区分 (mm)<br>DIMENSION | 公差 (mm)<br>TOLERANCE |
|------------------------|----------------------|
| $L \leq 50$            | $\pm 1.5$            |
| $50 < L \leq 100$      | $\pm 2.5$            |
| $100 < L \leq 500$     | $\pm 3$              |

- 注記
- 1) 指定外の寸法公差は表1による。
  - 2) #印寸法は最小サービスクリアランスとする。
  - 3) 取付方法は2種類から選択のこと。
  - ④の場合、ナベックピンネジ呼び径 $3 \times 20$ を使用のこと。
  - ⑤の場合、 $M3 \times 40$ 寸切ボルト、 $M3$ 平座金・バネ座金・バネナットを使用のこと。
- NOTE
1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.
  2. # MINIMUM SERVICE CLEARANCE.
  3. SELECT FOLLOWING METHOD FOR FIXING THE UNIT;
    - ④: USE TAPPING SCREWS  $\phi 3 \times 20$ .
    - ⑤: USE  $M3 \times 40$  STUD BOLTS,  $M3$  P.W./S.W./WING NUTS.


|          |             |             |               |                            |
|----------|-------------|-------------|---------------|----------------------------|
| DRAWN    | 2/Dec/08    | I. YAMASAKI | TITLE         | FI-507                     |
| CHECKED  | 3/Dec/08    | I. TAKENO   | 名称            | インストゥルメント (サーフェスマウント)      |
| APPROVED | 9/Dec/08    | R. ESUMI    | 外寸図           |                            |
| SCALE    | 1/2         | WASS 0.46   | NAME          | INSTRUMENT (SURFACE MOUNT) |
| DMC.No.  | C7277-G02-A | REF.No.     | 26-001-201G-0 | OUTLINE DRAWING            |

4-取付用下穴  
PILOT HOLES

表1 TABLE 1


| 寸法区分 (mm)<br>DIMENSION | 公差 (mm)<br>TOLERANCE |
|------------------------|----------------------|
| L ≤ 50                 | ±1.5                 |
| 50 < L ≤ 100           | ±2.5                 |
| 100 < L ≤ 500          | ±3                   |

取付穴寸法図  
CUTOUT DIMENSIONS



- 注記
- 1) 指定外の寸法公差は表1による。
  - 2) #印寸法は最小サービスマウント寸法とする。
  - 3) 取付用ネジはナベタツ呼び径3×20を使用のこと。
- NOTE
1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.
  2. # MINIMUM SERVICE CLEARANCE.
  3. USE TAPPING SCREWS φ3×20 FOR FIXING THE UNIT.

|          |             |             |               |                          |
|----------|-------------|-------------|---------------|--------------------------|
| DRAWN    | 3/Dec/08    | I. YAMASAKI | TITLE         | FI-507                   |
| CHECKED  | 4/Dec/08    | I. TAKENO   | 名称            | インストルメント (フラッシュマウント)     |
| APPROVED | 9/Dec/08    | R. ESUMI    | 外寸図           |                          |
| SCALE    | 1/2         | WASS 0.45   | NAME          | INSTRUMENT (FLUSH MOUNT) |
| DWG.No.  | C7277-G01-A | REF.No.     | 26-001-200G-0 | OUTLINE DRAWING          |



単品で使用するとき  
USING INDEPENDENTLY

インストゥルメント  
INSTRUMENT FI-501/502  
NMEA2K  
LTW12-05AFFM  
-SR7000

FI-50-DROP 6m, φ6

12VDC (+) アカ RED  
(-) クロ BLK  
\*3 [ NC シロ WHT  
アオ BLU ]

インストゥルメント  
INSTRUMENT FI-503/504  
505/506  
507  
NMEA2K

インストゥルメント  
INSTRUMENT FI-501/502  
NMEA2K

インストゥルメント  
INSTRUMENT FI-501/502  
NMEA2K


インストゥルメント (最大26個)  
INSTRUMENT (TOTAL: UP TO 26 SETS)  
NMEA2Kケーブル長総合計: 80m以下  
NMEA2K CABLE TOTAL LENGTH: UP TO 80m


ケーブルや接続条件により満足しない場合あり  
DEPEND ON CABLE AND CONNECTION CONDITIONS

- 注記
- \* 1) オプション。
  - \* 2) ケーブルを切断する場合は、ターミナルボックス (非防水) を使用のこと。
  - \* 3) 短絡しないように、端末を処理する。

- NOTE
- \*1: OPTION.
  - \*2: USE A TERMINAL BOX (NO-PROTECTION) WHEN THE SUPPLIED CABLE IS CUT.
  - \*3: PROTECT CABLE ENDS TO PREVENT SHORT-CIRCUIT.


|          |             |             |                         |                                |
|----------|-------------|-------------|-------------------------|--------------------------------|
| DRAWN    | 30/JAN/09   | I. YAMASAKI | TITLE                   | FI-501/502/503/504/505/506/507 |
| CHECKED  | 30/JAN/09   | T. TAKENO   | 名称                      | インストゥルメント                      |
| APPROVED | 5/FEB/09    | R. ESUMI    | 相互結線図                   |                                |
| SCALE    |             | MASS        | INSTRUMENT              |                                |
| DWG. No. | C7266-C01-F | REF. No.    | INTERCONNECTION DIAGRAM |                                |







FI-507サーフェスマウント用型紙  
FI-507 Surface Mount Template



$\oplus$   
タッピンネジ用穴 (4カ所)  
For tapping screws (4 pcs.)

寸切りボルト用穴 (4カ所)  
For bolts (4 pcs.)

$\oplus$

