



**SERIES 9900 WIRELESS INTERCOM SYSTEM**

**PUSH-BACK INTERCOM**

**U9920-GPB**

**PURGING INSTRUCTIONS**



## SERIES 9900 WIRELESS INTERCOM SYSTEM

First, turn off the Belt Station power by pressing the power button on the side of the unit



## SERIES 9900 WIRELESS INTERCOM SYSTEM

Next, push and hold the PTT switch on the front of the unit.



## SERIES 9900 WIRELESS INTERCOM SYSTEM

Then, push and **hold** the power button, powering the unit up, **while continuing to hold the PTT switch**



## SERIES 9900 WIRELESS INTERCOM SYSTEM



To complete the process, **when the LED indicator turns red, release the power button...**



...then release the PTT switch. The LED indicator will **flash red** For 15 to 20 seconds, followed by a voice prompt, "Connection Deleted."



## SERIES 9900 WIRELESS INTERCOM SYSTEM



The Push-Back Gateway also allows for a ***'full purge'***.

A full purge is a quick method of purging all linked Belt Stations at one time.



## SERIES 9900 WIRELESS INTERCOM SYSTEM



To execute a full purge, first turn off the Gateway – if not already off - by pressing the power button on the face of the unit.



POWER  
BUTTON





## SERIES 9900 WIRELESS INTERCOM SYSTEM



Next, push and hold the PTT switch on the face of the unit.



PTT  
SWITCH





## SERIES 9900 WIRELESS INTERCOM SYSTEM



Then, push and hold the power button until the power is on, indicated by the LED showing as solid red, while continuing to hold the PTT switch.



PTT  
SWITCH

POWER  
BUTTO  
N



## SERIES 9900 WIRELESS INTERCOM SYSTEM



Next, release the power button, while continuing to hold the PTT switch.



## SERIES 9900 WIRELESS INTERCOM SYSTEM

Finally, release the PTT button.



PTT  
BUTTON



## **SERIES 9900 WIRELESS INTERCOM SYSTEM**



All previously linked Belt Stations are now purged and ready to link again, when needed, to any 9900 Series Gateway.

