



Cup Chart

Part Number	Radio Models
Motorola	
MOT-1	GP300, P110, GP350, P1225/LS, LTS2000, GTX/LTR
MOT-2	HT750, HT1250LS, HT1550/LS/XLS, MTX850/LS, MTX950, MTX8250/LS, MTX9250, EX500, EX560, EX600, EX600XLS, GL200, PRO5150, PRO7150, PRO9150, PR860, Infinity P-1000, P1010
MOT-3	P040, P080, GP308, GP88S, CT150, CT250, CT450/LS, PRO3150
MOT-5/7	HT1000, MTX838, MTX1000, JT1000, MT1500, MT2000, MTS2000, MTX900, MTX9000, MTZ2000, MTX8000, MTXLS, XTS3000, XTS3500, XTS5000, PR1500, XTS1500, XTS2500
MOT-8	HT600, HT800, MT1000, P200, P210, MTX800
MOT-11	CP150, CP200, PR400
MOT-12	VL130, BC120, CP125, AXV5100, AXU4100, GP2000
MOT-13	MAG ONE/BPR40
MOT-14	MTP700
MOT-15	MOTO TRBO, XPR6300, XPR6500, XPR6350, XPR6380, XPR6550, XPR6580
MOT-18	Motorola CP185
EF Johnson	
EFJ-1	Viking 8500 Series
EFJ-2	Avenger 8100 Series
EFJ-4	EF Johnson 5100 series. Replaces EFJ-3. Supports latest Li-Ion battery models and all other chemistries. 5100ES series, 51 Fire ES, 51LT ES, 51SI ES series, ASCEND ES series, AN/PRC-127EFJ
Kenwood	
KEN-1	Radio Models: TK190, TK278, TK260, TK360, TK270, TK272G, TK370, TK280, TK372G, TK380, TK290, TK390, TK480, TK2100, TK3100, TK3101, TK3130, TK3131, TK481, TK5400 Battery Models: KNB14, KNB15, KNB16, KNB17, KNB17L, KNB20, KNB21, KNB22
KEN-2	Radio Models: TK250, TK350, TK253, TK353, TK430, TK431 Battery Models: KNB11, KNB12
KEN-3	Radio Models: TK2140, TK2160, TK3140, TK3160, TK2170, TK3170, TK2360, TK3360, TK3173 Battery Models: KNB24L, KNB25A, KNB26N, KNB35L, KNB40LC, KNB55L, KNB56N, KNB57L
KEN-4	Radio Models: TK2200, TK3200, TK2202, TK3202, TK2300, TK3300 Battery Models: KNB29, KNB30 KEN-4 supports these batteries when used only with the Ni-MH battery, the Li-ion battery requires KEN-6
KEN-5	Radio Models: TK2180, TK3180, TK5210, TK2180MPT, TK3180MPT, NX200, NX210, NX300, TK5220, TK5320, TK5410 Battery Models: KNB31, KNB32, KNB33L, I.S. battery KNB-41NC, KNB43L, KNB47L, KNB48L, KNB49PL, KNB50NC, KNB54N
KEN-6	Radio Models: TK2202, TK2212, TK3202, TK3212, TK2300, TK3300 Battery Models: KNB45L KEN-6 supports the slim Li-ion battery only, Ni batteries require KEN-4
Icom	
IC-1	Radio Models: IC-F3, IC-F4, IC-F3S, IC-F4S Battery Models: BP195, BP196
IC-2	Radio Models: F30GS, F40GS, IC-F3GT, IC-F4GT, IC-F4GS, IC-F21, IC-F21S, IC-F22, IC-F30GT, IC-F40GT, IC-F30GS, IC-F40G, F11 Battery Models: BP208, BP209, BP210, BP211
IC-3	Radio Models: IC-F3011, IC-F4011, IC-F3021T, IC-F3021S, IC-F4021T, IC-F4021S, IC-F3161DT, IC-F3161T, IC-F3161DS, IC-F3161S, IC-F4161DT, IC-F4161T, IC-F4161DS, IC-F4161S, IC-F14, IC-F14S, IC-F24, IC-F24S, IC-F43, IC-F43TR Battery Models: BP-230, BP232N, BP240
IC-4	Radio Models: IC-F50/F50V, IC-F60/F60V Battery Models: BP226, BP227, BP227FM
IC-5	Radio Models: IC-F70DT, IC-F70T, IC-F70DS, IC-F70S, IC-F80DT, IC-F80T, IC-F80DS, IC-F80S, IC-F9011T, IC-F9011S, IC-F9011B, IC-F9021T, IC-F9021S, IC-F9021B Battery Models: BP253, BP254, BP254FM, BP237
IC-6	Radio Models: IC-F3001, IC-F4001 Battery Models: BP236, BP264, BP265
Vertex	
VY-1	VX110, VX150, VX160, VX180, VX210, VX400, VX410, VX800, VXA12, VXA120, VXA200
VY-2	VX600, VX900
VY-3	VX500, VX510, VX530
VY-4	Battery Only: VX821, VX871, VX824, VX874, VX829, VX879 Radio & Battery or Battery Only: VX921, VX971, VX924, VX974, VX929, VX979
VY-5	VX354, VX230, VX231, VX351
Tait	
TA-1	Tait Radios: ORCA 5010, 5020, 5030, 5035, 5040, ORCA Elan, ORCA Excel, ORCA Eclipse M/A Com / Ericsson: Cougar 400P, Panther 400P, 600P, 625P
TA-2	TP8100 Series
TA-3	TP7110 Series



Cup Chart

Part Number	Radio Models
Harris / M/A Com / Tyco	
MA-3	EDACS 300P, PANTHER 300P
MA-5	LPE200, KPC300, KPC400, Prism, Panther 500P
MA-7	Jaguar 700P, P5100 series, 7100P, Unity XG-100P, P7370, P7350, P7230, P7250, P7270, P7130, P7150, P7170, P5450, P5470, P5350, P5370, P5200, P5130, P515
TA-1	Cougar 400P, Panther 400P, 600P, 625P
Maxon/Topaz	
MT3-2	SP150,SP1140,SP300,SP310/320,SP330/340, SP120,SP100, SL25, SL55 - Special Order Only
Midland/Allan/Key	
AMK-3	Alan HP-106 BP-0513/AP-0513Li - Special Order Only
AMK-4	Alan HP125K BP-3518Li - Special Order Only
Relm/Bendix King	
KEN-1	RPV Series
RBK-1	E,G,&L Series DPH 9.6V batteries. Note: Requires -V4 version charger
RBK-2	KNG-P150 Note: Requires -V4BK version charger
Novel/Entel/Ritron	
NOV-1	Novel NP-60, Entel HX series, Ritron SLX series
ENTEEL	
ENT-2	Entel HT series
HYT/HYTERA	
HYT-2	TC500 Series: TC-500-U1-110, TC500-U2-110, TC500-U2-220V, TC500-V1, TC500-V1-230V, TC500-V2, TC500-V2-230, BlackBox
HYT-3	TC600 Series: TC600U-1, TC600U-2, TC600V-2, TC600V-2-RFB, BlackBox+
HYT-4	TC700 Series: TC700, TC700FM, TC700MD, TC-700PT, TC780, TC780M
HYT-5	TC3600, TC3000, TC268, TC268S, TC368, TC368S, TC270, TC370, PT790
HYT-6	PD702G-U1, PD702G-V1, PD702U-1, PD702V-1, PD782G-U1, PD782U-1